

ECE321 – Electronics I

Lecture 3: Basic Solid State Physics

Payman Zarkesh-Ha

Office: ECE Bldg. 230B
Office hours: Tuesday 2:00-3:00PM or by appointment
E-mail: payman@ece.unm.edu

Review of Last Lecture

- Circuits with Nonlinear Devices (Diode)
- Diode Basic Characteristics
- Diode Approximations
- Diode Application Circuits (Rectifiers)

Today's Lecture

- Electrical Property of Materials**
- Energy Band Diagrams**
- Semiconductor Materials**
- n-Type and p-Type Semiconductor Materials**
- Mass Action Law**

Electrical Property of Materials


- Conductor: Low resistance material, like metals, that conducts electricity**

- Insulator: High resistance material, i.e. almost no current under applied voltage**


- Semiconductors: act as conductor or insulator (the basis for diodes and transistors)**

Conductivity from Atomic Perspective

Conductor



**Insulator
or
Semiconductor**




ECE321 - Lecture 3

University of New Mexico

Slide: 5

Energy Level and Energy Band Diagram

- The energy band shows the possible energy levels that an electron can obtain.
- The electrical property of the material depends on the energy gap (how tightly an electron is tied to the atom)




ECE321 - Lecture 3


University of New Mexico

Slide: 6

Electrical property using Band Diagram



Electron-Hole Pair Creation in Semiconductors



Density of electrons in intrinsic materials:



$$n_i = BT^{3/2} e^{\frac{-E_g}{2(kT/q)}}$$

$K = 1.381 \times 10^{-23} \text{ J/K}$
 $q = 1.602 \times 10^{-19} \text{ C}$
 $B = \text{Constant } (5.23 \times 10^{15} \text{ K}^{-3/2} \text{cm}^{-3} \text{ for Si})$
 $E_g = \text{Band Gap } (1.12 \text{ eV for Si})$

Example: In Silicon n_i at room temperature is $1.062 \times 10^{10} \text{ electrons/cm}^3$

Question: What is the density of holes in this case?

Extrinsic Semiconductors: n-Type



How to compute density of electrons and holes in extrinsic material?

Mass Action Law

If n_0 is the electron density and p_0 is the hole density in an extrinsic semiconductor then under thermal equilibrium we have:

$$n_0 p_0 = n_i^2$$

Let N_D be the density of donor atoms in an n-type semiconductor. At room temperature almost all of the donor atoms are ionized i.e. $n_0 = N_D$

Therefore:

$$n_0 p_0 = n_i^2 = N_D p_0 \quad \Rightarrow \quad p_0 = \frac{n_i^2}{N_D}$$

Example: n-Type Semiconductor

If $N_D = 10^{16}$ (donor atoms/cm³), calculate the minority concentration at $T = 300$ K.

Solution



$$n_o \approx N_D = 10^{16} \text{ (electrons/cm}^3\text{) and}$$

$$p_o = \frac{(1.062 \times 10^{10})^2}{10^{16}} = 1.128 \times 10^4 \text{ (holes/cm}^3\text{)}$$

n-Type semiconductor: Very large density of electrons but very small density of holes

Electrons : Majority Carrier
Holes : Minority Carrier

Extrinsic Semiconductors: p-Type



How to compute density of electrons and holes in extrinsic material?

Hole Density of p-Type Semiconductor

Let N_A be the density of acceptor atoms in an p-type semiconductor. At room temperature almost all of the acceptor atoms are ionized i.e. $p_o = N_A$

Therefore:

$$n_o p_o = n_i^2 = n_o N_A \quad \Rightarrow \quad n_o = \frac{n_i^2}{N_A}$$

Example: p-Type Semiconductor

If $N_A = 5 \times 10^{17}$ (acceptor atoms/cm³) calculate the minority carrier concentration at $T = 300$ K.

Answer:

$$n_o = 226 \left(\frac{\text{electrons}}{\text{cm}^3} \right)$$

p-Type semiconductor: Very large density of holes but very small density of electrons

**Holes : Majority Carrier
Electrons : Minority Carrier**